
Spare parts reference numbers of machine

- 1 Funnel
- 2 Funnel's gasket
- 3 Collar
- 4 Handwheel of the head's cover
- 5 Head's cover
- 6 Head's gasket
- 7 Pin
- 8 Towing gear
- 9 Towing axis gasket
- 10 Bronze bearing
- 11 Reducer axis
- 12 Micro head security
- 13 Reducer
- 14 Spacer
- 15 Foot's pivot
- 16 Rubber foot
- 17 Lock ring nut
- 18 Lower crankcase
- 19 Reducer plate
- 20 Activation block
- 21 Activation lever
- 22 Clamp
- 23 Handwheel
- 24 Activation micro
- 25 Electronic apparatus
- 26 Fan grid
- 27 Fan
- 28 Engine
- 29 Inverter
- 30 Command module
- 31 Display
- 32 Mushroom emergency stop push button
- 33 Pedal-board/Syringe socket
- 34 Pedal-board/Syringe plug
- 35 Unlock button
- 36 Main switch
- 37 Power switch
- 38 Accessories tray
- 39 Handle
- 40 Lid

- 41 Head
- 42 Idler gear
- 43 Idler pivot
- 44 Head handwheel
- 45 Seeger-ring
- 46 Towing pivot
- 47 Knurled screw
- 48 Big spout
- 49 Exit connection
- 50 Pedal-board
- 51 Pedal-board cable
- 52
- 53 Power cable
- 54
- 55 Power cable socket
- 56 Gears remover pliers
- 57 Small spout
- 58 Double spout
- 59 Tray pivots
- 60 Seal 25x37x7

Functional Diagram of Machine




MADE IN ITALY


Dosing machine

18

Exploded View of Machine



Replacement of O-ring of gear pin



Remove the gear (8 - 42) from the dosing head (41), then using a pliers to remove from its seat the seeger ring (45) located under the dosing head.


Press the gear towing pin (46) upwards until it is removed from its seat, replacing the O-ring seal 3081 (9).

To re-assemble , reposition the gear pin (46) in its seat, then put the seeger ring (45) back into place.


Spare parts reference numbers of syringe

- 34 Plug
- 35 Unlock button
- 48 Big spout
- 57 Small spout
- 58 Double spout
- 61 Syringe body
- 62 Stat button
- 63 Hook
- 64 Handle
- 65 Lower knurled screw
- 66 Hose clamp
- 67 Product pipe
- 68 Electrical cable
- 69 Connection
- 70 Knurled screw

Functional Diagram of Syringe



Exploded View of Syringe



Spare parts reference numbers of lobes head

- 4 Hanwheel of head cover
- 84 Lobes head fixing pin
- 85 Lobe
- 86 Driven axis
- 87 Drive axis
- 88 O-ring 3081 Viton
- 89 O-ring 3450
- 90 Upper lobes head
- 91 Drive gear wheel
- 92 Driven gear wheel
- 93 O ring 3375
- 94 Seal
- 95 Lower part of the lobes head
- 96 Cover lobes head

Exploded view of lobes head

